



Technical Data

Nexus Grid Rockers

Brief product description:

The Nexus Grid range is ideal for domestic, commercial and industrial applications. The Grid range matches wider Nexus finished to provide an extended range.

Features:

- Replacement rockets available in all finishes
- Plastic – printed, metal – embossed
- Supplied in bags of 10
- Easy to fit on standard grid switch modules


Product Images



Range Options

White	Chrome	Brushed Steel	Black Nickel	Polished Brass	Description
GRHBW	GRHBPC	GRHBBS	GRHBBN	GRHBPB	Printed - Hob
GROVW	GROVPC	GROVBS	GROVBN	GROVPB	Printed - Oven
GRFNW	GRFNPC	GRFNBS	GRFNBN	GRFNPB	Printed - Fan
GRMWW	GRMWPC	GRMWBS	GRMWBN	GRMWPB	Printed - Washing Machine
GRTDW	GRTDPC	GRTDBS	GRTDBN	GRTDPB	Printed - Tumble Dryer
GRFDW	GRFDPC	GRFDBS	GRFDNB	GRFDPB	Printed - Fridge
GRFZW	GRFZPC	GRFZBS	GRFZBN	GRFZPB	Printed - Freezer
GRBLW	GRBLPC	GRBLBS	GRBLBN	GRBLPB	Printed - Boiler
GRMWW	GRMWPC	GRMWBS	GRMWBN	GRMWPB	Printed - Microwave
GRCHW	GRCHPC	GRCHBS	GRCHBN	GRCHPB	Printed - Cooker Hood
GRHWW	GRWHPC	GRWHBS	GRWHBN	GRWHPB	Printed - Water Heater
GRWDISW	GRWDISPC	GRWDISBS	GRWDISBN	GRWDISPB	Printed - Waste Disposal
GRACW	GRACPC	GRACBS	GRACBN	GRACPB	Printed - Air Conditioning
GRDWW	GRDWPC	GRDWBS	GRDWBN	GRDWPB	Printed - Dish Washer
GRBELLW	GRBELLPC	GRBELLBS	GRBELLBN	GRBELLPB	Printed - Bell Symbol
GRFFW	GRFFPC	GRFFBS	GRFFBN	GRFFPB	Printed - Fridge Freezer
GRHTW	GRHTPC	GRHTBS	GRHTBN	GRHTPB	Printed - Heater
GRUPW	GRUPPC	GRUPBS	GRUPBN	GRUPPB	Unprinted Rocker
GRUPG	-	-	-	-	Unprinted Graphite Rocker (Part M)


Line Diagrams



Nexus Grid Rockers

Replacement/Interchangeable

Replacement rockers - Switch modules are supplied with plain rockers, however a selection of pre-printed rockers are available.



To replace:

- Remove existing rocker by inserting screwdriver under rocker cap and lifting.
- Position replacement cap into aperture and clip into place ensuring text is correctly aligned in relationship to top of module.

General Assembly Guide

Step 1:

Fit and secure appropriate mounting box and frame. Please see Note 1 for additional assembly instructions required that are relevant to the plate type being installed -

- Pull cabling through frame and strip insulation accordingly.
- Ensure an earth connection between frame and box (if required).
- Systematically terminate cables into each module.

Step 2:

To fit module to frame -

- Locate groove in lower edge of module over lower edge of aperture in frame and pivot upwards locating the pegs on the module into holes in frame and clip into place.
- It is recommended to decorate wall before fixing front-plate.
- Attach front-plate using fixing screws provided or push for secure clip-on. For Screwless front-plates please see Note 2 for additional assembly instructions.

Note 1:

For White Moulded, Nexus Metal and Brass Georgian - remove the two plastic spacers and discard. For Metal Clad and Grid - bend the four lugs down where indicated by the V notches and ensure plastic spacers are fitted.





The position of the frame in relationship to the wall can be adjusted by the two captive fixing screws.

For Decorative Flatplate - Before fixing the frame to the wall ensure that the gasket supplied is correctly positioned between the frame and the wall.

Note 2:

Decorative Flatplate - When fitting ONE or THREE modules to the screwless Flatplate grid frame, the blanking strips supplied must be fitted either side of the module(s) to prevent access to the wiring.

Frontplate - should be fitted with the removable notch located over the angled face of the gasket in the lower right hand corner.



Nexus Grid Rockers

Packaging Information

Cat No.	Description	Packaging Type			Pack Quantity			Barcode		
		Product	Inner Box	Outer Box	Product	Inner Box	Outer Box	Packed Product	Inner Box	Outer Box
GRHBPC	Printed - Hob	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765015011	5050765016384	5050765017756
GROVPC	Printed - Oven	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765015028	5050765016391	5050765017763
GRFNPC	Printed - Fan	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765015035	5050765016407	5050765017770
GRWMPC	Printed - Washing Machine	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765015042	5050765016414	5050765017787
GRTDPC	Printed - Tumble Dryer	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765015059	5050765016421	5050765017794
GRFDPC	Printed - Fridge	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765015066	5050765016438	5050765017800
GRFZPC	Printed - Freezer	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765015073	5050765016445	5050765017817
GRBLPC	Printed - Boiler	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765015080	5050765016452	5050765017824
GRMWPC	Printed - Microwave	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765015097	5050765016469	5050765017831
GRCHPC	Printed - Cooker Hood	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765015103	5050765016476	5050765017848
GRWHPC	Printed - Water Heater	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765015110	5050765016483	5050765017855
GRWDISPC	Printed - Waste Disposal	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765015127	5050765016490	5050765017862
GRACPC	Printed - Air Conditioning	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765015134	5050765016506	5050765017879
GRDWPC	Printed - Dish Washer	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765015141	5050765016513	5050765017886
GRBELLPC	Printed - Bell Symbol	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765032384	5050765033282	5050765034180
GRFFPC	Printed - Fridge Freezer	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765045070	5050765045186	5050765045292
GRHTPC	Printed - Heater	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765045124	5050765045230	5050765045346
GRUPPC	Unprinted rocker	Bag	Colour Box	Carton	10	100 packs	1000 packs	5050765015158	5050765016520	5050765017893

Weights & Dimensions

Cat No.	Description	Dimensions (L x W x D) cm			Weight (kg)			CBM m ³
		Unpacked Product	Inner Box	Outer Box	Unpacked Product	Inner Box	Outer Box	Outer Box
GRHBW	Printed - Hob	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GROWW	Printed - Oven	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFNW	Printed - Fan	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRWMW	Printed - Washing Machine	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRTDW	Printed - Tumble Dryer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFDW	Printed - Fridge	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFZW	Printed - Freezer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRBLW	Printed - Boiler	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRMWW	Printed - Microwave	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRCHW	Printed - Cooker Hood	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRWHW	Printed - Water Heater	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRWDISW	Printed - Waste Disposal	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRACW	Printed - Air Conditioning	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRDWW	Printed - Dish Washer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRBELLW	Printed - Bell Symbol	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFFW	Printed - Fridge Freezer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRHTW	Printed - Heater	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRUPW	Unprinted rocker	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRUPG	Unprinted Graphite rocker	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRHBBS	Printed - Hob	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GROVBS	Printed - Oven	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFNBS	Printed - Fan	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRWMBS	Printed - Washing Machine	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRTDBS	Printed - Tumble Dryer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFDBS	Printed - Fridge	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFZBS	Printed - Freezer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRBLBS	Printed - Boiler	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRMWBS	Printed - Microwave	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRCHBS	Printed - Cooker Hood	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRWHBS	Printed - Water Heater	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRWDISBS	Printed - Waste Disposal	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRACBS	Printed - Air Conditioning	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRDWBS	Printed - Dish Washer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRBELLBS	Printed - Bell Symbol	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFFBS	Printed - Fridge Freezer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRHTBS	Printed - Heater	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRUPBS	Unprinted rocker	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRHBBS	Printed - Hob	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GROVBN	Printed - Oven	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFNBN	Printed - Fan	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRWMBN	Printed - Washing Machine	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRTDBN	Printed - Tumble Dryer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFDBN	Printed - Fridge	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFZBN	Printed - Freezer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRBLBN	Printed - Boiler	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRMWBN	Printed - Microwave	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRCHBN	Printed - Cooker Hood	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRWHBN	Printed - Water Heater	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01

Nexus Grid Rockers

Weights & Dimensions

Cat No.	Description	Dimensions (L x W x D) cm			Weight (kg)			CBM m ³
		Unpacked Product	Inner Box	Outer Box	Unpacked Product	Inner Box	Outer Box	Outer Box
GRWDISBN	Printed - Waste Disposal	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRACBN	Printed - Air Conditioning	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRDWBN	Printed - Dish Washer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRBELLBN	Printed - Bell Symbol	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFFBN	Printed - Fridge Freezer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRHTBN	Printed - Heater	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRUPBN	Unprinted rocker	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRHBPB	Printed - Hob	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GROVPB	Printed - Oven	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFNPB	Printed - Fan	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRWMPB	Printed - Washing Machine	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRTDPB	Printed - Tumble Dryer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFDPB	Printed - Fridge	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFZPB	Printed - Freezer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRBLPB	Printed - Boiler	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRMWPB	Printed - Microwave	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRCHPB	Printed - Cooker Hood	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRWHPB	Printed - Water Heater	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRWDISPB	Printed - Waste Disposal	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRACPB	Printed - Air Conditioning	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRDWPB	Printed - Dish Washer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRBELLPB	Printed - Bell Symbol	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFFPB	Printed - Fridge Freezer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRHTPB	Printed - Heater	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRUPPB	Unprinted rocker	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRHBPC	Printed - Hob	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GROVPC	Printed - Oven	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFNPC	Printed - Fan	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRWMPC	Printed - Washing Machine	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRTDPC	Printed - Tumble Dryer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFDPC	Printed - Fridge	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFZPC	Printed - Freezer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRBLPC	Printed - Boiler	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRMWPC	Printed - Microwave	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRCHPC	Printed - Cooker Hood	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRWHPC	Printed - Water Heater	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRWDISPC	Printed - Waste Disposal	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRACPC	Printed - Air Conditioning	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRDWPC	Printed - Dish Washer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRBELLPC	Printed - Bell Symbol	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRFFPC	Printed - Fridge Freezer	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRHTPC	Printed - Heater	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01
GRUPPC	Unprinted rocker	1.3 x 2.6 x 0.6	8.5 x 11.5 x 8.8	14 x 45 x 19	0.003	0.40	4.40	0.01